

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

753537
End Table

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!




1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.






ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	TOP		1PC
B	LEG		3PCS
C	CROSSBAR		1PC


HARDWARE IDENTIFICATION

1	BOLT (JCBB M8 X 50mm)		6PCS
2	ALLEN WRENCH (M5 - BLK)		1PC
3	WOOD PLUG		6PCS


ITEM: **753537**

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM: **753537**




ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4

COMPLETE



ITEM: **753537**



Note : Dimension tolerance $\pm 5\%$