## Vogue Riverside Page 1 of 2 Home Office Made in Viet Nam Assembly Instructions info@riverside-furniture.com email: Components and Hardware List End Frame DESK TOP Back Stretcher (Right & Left) (B)(C)1 pc. 2 pcs. 1 pc. 5/16"x19\*2mm 5/16" Spring $M5/16" \times 1-3/8"$ Flat Washer Allen Head Bolt Washer (D)16 pcs. 16 pcs. M5/16" x 5/8" 5mm Allen Wrench 'L' Bracket #46030-46130-46230 Allen Head Bolt

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.

2 pcs.

Writing Desk


Step 1. Place the Writing Desk Top (A) and End Frames (B) face down on a clean and soft surface.

4 pcs.

(G)

1 pc.

Step 2. Assemble the L-Brackets (L) to the End Frames using the Allen Head Bolts (H) Spring Washers (F) and Flat Washers (E). Check that they are oriented correctly and tighten with the Allen Wrench (G) as shown.



Riverside

Vogue Home Office Assembly Instructions

Page 2 of 2

Made in Viet Nam

email: info@riverside-furniture.com

- Step 3. Connect the End Frames (B) to the proper end of the Desk Top using the Allen Head Bolts (D), Spring Washers (F), and Flat Washers (E). Only partially install bolts until the entire Desk has been assembled.
- Step 4. Install the Back Stretcher (C) between the two End Frames.
- Step 5. Tighten Bolts previously installed using the 5mm Allen Wrench.
- Step 6. Connect the ends of the Back Stretcher using the Allen Head Bolts (H), Spring Washers (F) and Flat Washers (E). While pulling end of Stretcher snug to the End Frame, tighten bolts using the 4mm Allen Wrench (G).

