

VERSAILLE / BELLE ROSE DECORATIVE TRIM SIDE ASSEMBLY

Each Bed Side Rail includes two lower decorative trims which must be attached to the side rails prior to bed assembly. (Use of decorative trims are options)

- 1. Turn Side Rail Upside Down and match trim piece to the end of the rail.
- 2. Trims must be mounted flush to rear and front bed rail as shown in drawing.
- 3. Cleat on the decorative trim should line up flush to the side rail mattress support cleat.
- 4. Use screws provided to secure trim pieces.

