

CARBONCOOL™ MATTRESS TOPPER CARE INSTRUCTIONS

BEFORE USE

- Carefully remove plastic packaging. Take care not to cut through the mattress topper.
- Place compressed mattress topper on a flat surface in a well ventilated room and allow 48 hours for expansion.
- Due to the unique properties of memory foam, dimensions after expansion may vary; this is normal and will not affect the performance of the topper.
- New memory foam may initially have a slight odor; it is completely harmless and will dissipate over a short time with regular use.

WASHING CARE

- Spot cleaning is recommended for the topper cover. Removing this cover can damage the phase change material coating.