

Crate Style Bed Assembly Instructions

Contents: sizes vary depending on model ordered

- (A) = 1 headboard
- (B) = 1 footboard
- (C) = 2 bed rails (75" or 80" long)
- (D) = 9 slats (twin = 40-1/4", double = 55-1/4", queen = 61-1/4", king = 79-1/2" long)
- (E) = 8 connector bolts (100mm long)
- (F) = 8 cross dowels
- (G) = 18 wood screws
- (H) = 1 Allen key
- (I) = 1 centre rail (king size only)

Tools required:

- Slotted screwdriver
- #2 Robertson or Phillips screwdriver

(E) connector bolt (F) cross dowel (G) wood screw (H) Allen key



Please read all instructions before beginning

1. Assemble bed using 2 bed rails (C), 1 headboard (A), 1 footboard (B), 8 connector bolts (E), with 8 cross dowels (F). Refer to "Figure 1" for correct position of bed rail, bed end and hardware.
2. King bed only: slide centre rail (I) into the slots in the headboard and footboard. If a trundle bed is being added, move the centre rail brackets off-centred as required.
3. Slide 9 slats (D) into bed rail grooves and secure each slat with 2 wood screws (G) using predrilled holes, refer to "Figure 2". Position 1 slat 3" from each bed end and 7 evenly spaced in between. Ensure that the spaces between slats are less than 3 1/2".

