



QUARTZ SINKS

Installation Guide and Users Manual



ATTAINABLE LUXURY®



REGISTERING YOUR PRODUCT

Please register your ZLINE appliance to activate your warranty. Begin the simple registration process by scanning the QR code.

By registering your appliance, you will have access to:

- Technical Support
- Warranty Service
- Tracking your support inquiries

▲ WARNING: This product can expose you to chemicals including nickel, which is known to the State of California to cause cancer. For more information, go to www.P65Warnings.ca.gov.

ZLINE Kitchen and Bath provides Attainable Luxury, where the kitchen and bath of your dreams is never out of reach. Through our unique designs and unparalleled quality, we're dedicated to providing you an elevated experience in the heart of your home. With an endless selection of features and finishes, our inspiration is your reality.

ZLINE is fueled by a passion for innovation; A relentless pursuit of bringing the highest end luxury designs and professional features into everyone's homes. Because we continually strive to improve our products, we may change specifications and designs without prior notice.

TABLE OF CONTENTS

| SAFETY INSTRUCTIONS | 1 |
|-----------------------------|---|
| BEFORE INSTALLATION | 2 |
| TOP MOUNT SINK INSTALLATION | 3 |
| UNDERCOUNTER INSTALLATION | 4 |
| MAINTENANCE AND CLEANING | 5 |

SAFETY INSTRUCTIONS

- The installer and/or user must read, understand, and follow these instructions before installing the product. This product must be properly installed before it is used. If instructions are not followed, the manufacturer will not be held responsible for any problems or product malfunction. Failure to follow installation and/or operating instructions voids the warranty.
- We recommend that this product be installed by a certified plumber. In some states or provinces, it is a legal requirement for this type of product to be installed by a certified plumber, according to the plumbing and building codes effective in the region where the sink is used.
- Shut off the water valves before installing the sink or doing any maintenance.
- Open the sink packaging and verify that the sink is in perfect condition. Put the sink back in its packaging to protect it until time of installation.
- To replace a sink, ensure that the hole in the counter is adequate.
- Templates are supplied only as a guide. Be sure to refer to the physical sink for accurate measurements of the countertop cut-out hole.

ZLINE

BEFORE INSTALLATION

BEFORE INSTALLATION

Inspect the sink for any visible defects. Do not install the sink if defects are found. Call customer service at 1-614-777-5004 for assistance.

TOOLS NEEDED

- Cutting tools appropriate for the countertop surface
- Tape measure
- Drill •
- 2x4 support frame
- Masking tape
- Sealant
- Screwdriver
- Pencil
- Ball-peen hammer
- Cloth

INSTALLATION

TOP MOUNT INSTALLATION

- 1. Preparing the Cabinets
- Make sure that the tank will not interfere with cabinet doors or panels. Ensure that there is enough space for the water supply installation.

2. Use Template for Cutting Into Counter Top

- Use the actual sink for verification of exact measurements.
- Position template on the countertop surface and trace the cut line with a pencil. •
- Make sure that the sink is perfectly centered and the outline is parallel to the counter.
- Place masking tape along the center of the cut line to avoid chipping or scratching caused by the cutting tool.
- Cut inside the template line to create the opening.

3. Build a Support Frame

• Quartz sinks need support due to their weight. Install 2x4s underneath the sink to reinforce it. Create both vertical and horizontal supports.

4. Insert Sink

- Insert sink on to the support frame so that the sinks sits above the countertop, making sure the height of the sink is acceptable before siliconing the edges.
- Make sure that the sink sits as close as possible to the cabinet top. It should be hard to slide a piece of paper through the gap between the sink and the countertop. Once the height is acceptable, proceed to use a silicone-based sealant.
- Place the sealant on the outside of the sink along the edges where the sink meets the countertop.

ZLINE

INSTALLATION

UNDERCOUNTER INSTALLATION

NOTE: The cutting board supplied may not work as designed.

- 1. Preparing the Cabinets
- Make sure that the tank will not interfere with cabinet doors or panels. Ensure that there is enough space for the water supply installation.
- 2. Use Template for Cutting Into Counter Top
- Use the actual sink for verification of exact measurements.
- Position template on the countertop surface and trace the cut line with a pencil.
- Make sure that the sink is perfectly centered and the outline is parallel to the counter.
- Place masking tape along the center of the cut line to avoid chipping or scratching caused by the cutting tool.
- Cut inside the template line to create the opening.

3. Build a Support Frame

- Quartz sinks need support due to their weight. Install 2x4s underneath the sink to reinforce it. Create both vertical and horizontal supports.
- 4. Insert Sink
- Insert the sink on the support frame.
- Apply silicone-based sealant to each corner and between the frame and the sink.

MAINTENANCE AND CLEANING

Quartz sinks composed of 80% quartz sand and 20% acrylic resin, which makes the surface non-porous, ensuring high levels of hygiene. The non-porous surface does not support bacterial growth. As a result, no harsh chemical cleaners are required to maintain your sink in its original condition. Basic care and maintenance will ensure your sink's long-lasting luster.

EVERY DAY CARE

- To maintain a quartz sink, clean it thoroughly after every use, rinsing with mild soap and warm water.
- To prevent mineral deposit build-up, it's important to keep the sink free of any standing water by wiping dry after every use.
- For additional preventive cleaning, rub lightly with a scouring pad and a mild cleaner.
- To prevent metal utensils, pots and other metal objects from leaving metal residue on the bottom of the sink, use stainless steel bottom grids.

MINERAL DEPOSITS

• Wipe the sink using a solution of water and white vinegar. Rinse the sink with fresh water after 20 minutes.

MARKS FROM METAL OBJECTS

• Rub in circular motion using a scouring pad and a mild cleaner.

AVOID THESE:

- Do not use metal scrubs or steel wool.
- AVOID USING ABRASIVE CLEANERS SUCH AS CONCENTRATED BLEACH, PAINT REMOVERS, AND DRAIN CLEANERS.
- DO NOT LEAVE WATER IN THE SINK FOR AN EXTENDED PERIOD OF TIME.
- AVOID LEAVING METAL OBJECTS SUCH AS STEEL OR CAST POTS AND UTENSILS IN THE SINK FOR A LONG PERIOD OF TIME.
- DO NOT LEAVE WET SPONGES, RUBBER MATS, OR CLEANING CLOTHS IN THE SINK FOR A LONG PERIOD OF TIME.

Ζ







1-614-777-5004 contact@zlinekitchen.com

www.zlinekitchen.com