

email: info@riverside-furniture.com

Sheffield Home Office Assembly Instructions

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Separate, count and check all parts against the Components and Hardware List below.

Component And Hardware List

Top Assembly

Leg Frame
Left

Right

Back Stretcher



Made in Viet Nam

Ø5/16-20 x 50mm


Allen Head Bolts:



8 PCS. G







1 PC.





Page 1 of 2

Furniture Tipping Restraint Kit

To prevent possible scratches, assemble on a soft surface such as a blanket or carpet.



NOTE: Do not fully tighten bolts until the desk is completely assembled. Then tighten all bolts using the supplied allen key.

