

ASSEMBLY INSTRUCTION

Item: 5447-75700 Ladderback Arm Chair w/ Upholstered Seat

5447-75700 TOFFEE

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process:

HARDWARE PACK

NO	DRAWING	DESCRIPTION	SIZE	Q'TY
A	Samme.	SCREW	#8×1-1/4"	8pcs
В		BOLT	$\Phi 5/16" \times 1-3/4"$	2pcs
С	STATE OF THE PARTY	BOLT	$\Phi 5/16" \times 3-1/4"$	4pcs
D		NUT	$\Phi 5/16" \times 12$	4pcs
Е	0	FLAT WASHER	Φ 5/16"×19×2	10pcs
F	٥	LOCK WASHER	Φ 5/16" \times 12 \times 3	10pcs
G	₹ 1	WRENCH	12mm	1pc
Н	0.7	BOLT	$\Phi 1/4" \times 1-1/4"$	2pcs
I	0	FLAT WASHER	Φ 1/4" \times 13 \times 2	2pcs
J	٥	LOCK WASHER	Φ 1/4" \times 12 \times 3	2pcs
K		ALLEN WRENCH	4mm	1pc
L	\bigcirc	WOOD PLUG	Φ 15 × Ø13 × 10	2pcs



