

## Item#24665 Parts list

Front Panel	1 pc
side panel	2 pcs
top frame	1 pc
tempered glass	1 pc

## **Assembly Instruction Hardware list**

Screw	11 pcs
Spanner	1 pc
Rubber bumper	8 pcs



1. Take all parts out of the carton carefully and place on a clean flat surface.



2.Screw the two side panels into the front with screws as illustrated A.

3.Screw top frame as illustrated B with screws.



4.Push rubber bumpers into the holes as illustrated C .Once rubber bumpers are in place, lay the glass on the rubber bumpers.



5.Use spanner to secure tightly.

Assembly is complete.