



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

224344
Mirror

ITEM: **224344**

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING !



- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2 . This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES


PARTS IDENTIFICATION

A MIRROR




1PC

B MIRROR SUPPORT
(PACKED WITH MIRROR)



2PCS

C DRESSER
FROM BOX ITEM #224343



1PC

HARDWARE IDENTIFICATION

1 BOLT
(M6 x 35mm - BLK)



8PCS

2 LOCK WASHER
(1/4" - BLK)



8PCS

3 FLAT WASHER
(1/4" x 20mm - BLK)



8PCS

4 ALLEN WRENCH
(M4 x 65mm - BLK)




1PC


NOTE:

Philips head screw driver in the assembly process ; however, manufacturer does not provide the item


ITEM: **224344**
ASSEMBLY INSTRUCTIONS
STEP 1



STEP 2




STEP 3
COMPLETE



ITEM: **224344**



INNER SIZE OF MIRROR : 0.16" X 33.15" X 35.79"



Note: Dimension tolerance $\pm 5\%$