








OUTDOOR COLLAPSIBLE GAZEBO
CO9103



PART LIST

<div data-bbox="108 114 139 141" data-label="Text">A</div> 	<div data-bbox="313 114 344 141" data-label="Text">B</div> 	<div data-bbox="512 114 543 141" data-label="Text">C</div> 
<div data-bbox="150 302 253 349" data-label="Text">Carry Bag 1 PC</div>	<div data-bbox="367 302 440 349" data-label="Text">Frame 1 PC</div>	<div data-bbox="538 302 642 349" data-label="Text">Top Cover 1 PC</div>

HARDWARE LIST

<div data-bbox="103 604 134 631" data-label="Text">#1</div> 	<div data-bbox="310 604 341 631" data-label="Text">#2</div> 
<div data-bbox="176 792 243 840" data-label="Text">Peg 8 PCS</div>	<div data-bbox="362 792 481 840" data-label="Text">Guide Rope 4 PCS</div>


ADDITIONAL TOOLS(Not Provided)




Rubber Mallet

Note: At least 2 people are required for assembly.



Step 1. Stand the Gazebo Frame (Part B) upright immediately. With people at diagonally opposite corners, carefully pull the Gazebo partly open. Move to each side, carefully pulling the frame apart until it has expanded as shown.



Step 2. Place the Top Cover (Part C) over the frame and attach to the center pole especially attach four corners of Top Cover (Part C) to four corners smoothly. Lift the canopy to reveal the framework. With people at opposite sides, push up and down on the frames as shown. Move to each side, carefully pushing (compressing) the frame together. After that, pulling the legs from each side carefully to make the top cover fit the frame closely.



Step 3. In one corner at a time,lock the Gazebo frame in position by sliding the corner bracket up until the spring clip engages into the bracket. Pull and extend each leg down until the spring clips engage into the hole in the outer tubes,At the same time tie the Velcro to side and cross poles.From inside,check that each of the frame sides are as shown.




Finished position of frame sides - Do not compress any more.

Step 4. Secure the Gazebo to the ground at each corner. Insert a peg (Part #1) through the hole in each frame leg into the ground using a rubber mallet. Attach the hooks on the end of the canopy legs to the holes at the end of the frame legs, the canopy cover can be tightened by moving the hooks to a lower hole.



Step 5. Attach the end of each guy rope (Part #2) to a fabric ring at each corner of the canopy cover. Use the pegs (Part #1) to secure the other end of the guy rope to the ground.



Taking down the Gazebo

Take care when dismantling the Gazebo and do not force the frame.

a. Remove the guide ropes and pegs.

b. Unhook the canopy from the frame legs and remove the pegs.



c. Push in the spring clips and slide the frame legs up.




d. Push in the spring clips and (slightly) lower the corner brackets.



e. Undo the Velcro and take off the top cover.

f. With people at diagonally opposite corners, carefully lift and push the Gazebo together.



g. Store all of the components and fittings in the Carry Bag (Part A) provided.