

Dimensions


A - Seat Depth - 21.5" / 55cm B - Seat Height - 18.5" / 47cm C - Arm Height - 24" / 61cm

Features

- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- Back filled with blown fibre

77325 ATTICUS

Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice. LHF - left hand facing RHF - right hand facing IA - inside arm to inside



01 Sofa 94 x 36 x 32" 239 x 91 x 81cm IA: 78" / 198cm



14 Armless Loveseat 52 x 36 x 32" 132 x 91 x 81cm




02 Chair 41 x 36 x 32" 104 x 91 x 81cm IA: 26" / 66cm



15 RHF Chaise 16 LHF Chaise 34 x 57 x 32" 86 x 145 x 81cm



03 Loveseat 67 x 36 x 32" 170 x 91 x 81cm IA: 52" / 132cm



40 RHF Sofa Split

39 LHF Sofa Split

239 x 91 x 81cm

94 x 36 x 32"

91 Apartment Sofa 79 x 36 x 32" 201 x 91 x 81cm IA: 64" / 163cm

26 x 18 x 18"

66 x 46 x 46cm



08 RHF Loveseat 07 LHF Loveseat 60 x 36 x 32" 152 x 91 x 81cm



10 Armless Chair 26 x 36 x 32" 66 x 91 x 81cm

77325 ATTICUS



How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty

Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty

