


AMANA®

30" ELECTRIC FREESTANDING SELF CLEAN RANGE

MODELS:

ACR4303MMS0 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5	3196178	Screw	11	814399	Receptacle, Element
	W11509598	User Instructions	6	3195812	Rod, Support			FOLLOWING PARTS NOT ILLUSTRATED
	W11401726	Tech Sheet	7	7101P485-60	Screw, Anti-Tip Kit			
	W11481066	Quick Start Guide	8	3196154	Screw	W11452635		Harness, Main
2	W10196406	Bowl, Drip (6") (Right Front and Left Rear)	9	W11364018	Element, Coil Heating (1500W) (Right Front and Left Rear)	W11134595		Harness, Cooktop
	W10196405	Bowl, Drip (8") (Left Front and Right Rear)		W11364019	Element, Coil Heating (2400W) (Left Front and Right Rear)	W10281322		Kit, Bare Wire Adapter Block
3		Cooktop						
	3186233	Black	10	W11379945	Bracket, Anti-Tip			
4	3195060	Hinge, Cooktop						


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	5	3196169	Screw	13	3196178	Screw
	W11130372	Black (Left)	6	3400882	Screw	14	3196200	Clip, Spring
	W11130379	Black (Right)	7		Knob, Infinite			
2	W10695491	Bracket, Control		W10844801	Black			
3		Panel, Control	8	W10134247	Shield, Heat			
	W11157014	Stainless	9	3196165	Screw			
4	3148952	Switch, Infinite (Yellow)	10	8272473	Cover, Upper Rear			
		(Right Front and Left Rear)	11	W10525121	Bracket, Console Mounting			
	3148954	Switch, Infinite (Orange)	12		Control, Electronic (LCX)			
		(Left Front and Right Rear)		W11511568	Black			

CHASSIS PARTS




CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11222267	Tube, Vent
2	W10209613	Box, Burner
3		Panel, Side
	W10162245	Black
4	W11173792	Rack, Oven
5	W10129032	Seal, Door
6	W10308476	Element, Broil
7	W11022836	Element, Bake
8	3400029	Nut
9	3196548	Fuse, Thermal
10	3196169	Screw
11	W10341186	Front Foot Assembly
12	W10067840	Screw
13	8054068	Retainer, Insulation
14	W10137382	Clip, Panel

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
15	W10390008	Base Rail Assembly (Left)
	W10390007	Base Rail Assembly (Right)
16	W10058460	Foot, Leveling
17	W10289077	Receiver, Hinge
18	3196172	Screw
19	W10404688	Clip, Oven Support
20	W10674705	Glide, Drawer Front
21	W10245259	Block, Terminal
22	W11034869	Screw
23	3196174	Screw
24	W11544377	Light Assembly
25	W10571723	Bulb, Halogen 40 Watts
26	3196567	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
27	W10181986	Sensor, Oven
28	3196165	Screw
29	3186034	Bracket, Service
30	3196178	Screw
31	3400016	Screw
32	W10326122	Cover, Terminal Block
33	W10910404	Counterweight
34	W11464547	Bracket, Front Frame
35	3196560	Screw
36	W11510560	Barrier Rail, Rubber (Left & Right)
		FOLLOWING PARTS NOT ILLUSTRATED
	8273263	Insulation, Wrap
	8272611	Insulation, Back


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Top	8		Glass Assembly, Outer Door	13	W10327235	Screw
	W10310922	Black				14	3196165	Screw
2	W10168559	Screw		W11602914	Stainless	15	W10031790	Screw
3		Handle, Door	9	9761505	Retainer, Insulation	16	W10200660	Screw
	W10323589	Black	10	W10299225	Hinge, Active	17	W10031780	Screw
4	9761344	Liner, Door	11	W11379944	Strap, Door	18		Badge
5	W10137382	Clip, Panel	12		Trim, Side		W10846752	Stainless
6	W11367326	Glass, Inner		W10746436	Black (Left)			
7	W10299227	Hinge, Door (Passive)		W10746435	Black (Right)			

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3196165	Screw	3	W10462910	Bracket, Mounting Drawer	5		Panel, Front
2	W10688022	Drawer, Storage	4	W10674708	Glide, Drawer Rear		W10330070	Stainless

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	206922	Primer (White)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	3184478	Cleaner, Glass
	4396923	Broiler Pan and Grid