




GAS DRYER

MODELS:

WGD4950HW2 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6	W10556829	Panel, Rear (Console)	16		Top
	W11361424	Owners Manual	7	W10661453	Switch, Temperature		8559800	White
	W11355746	Quick Start Guide	8		End Cap (Right)	17	W10117655	Switch, Push To Start
	W11366444	Cycle Guide		W10520780	White	18		Assembly, Control Knob
	W10876312	Wiring Diagram	9	693995	Screw		W10770858	White/Metallic
2		Assembly, Control Panel	10		Lint Screen	19		Assembly, Timer Knob
	W11178665	White		W11451394	White		W10770866	White/Metallic
3	694419	Buzzer, Mini	11	8536939	Clip, Spring	20	W10185981	Assembly, Timer (60 Hz.)
4		End Cap (Left)	12	3400818	Screw	21	W11523105	Harness, Main
	W10520782	White	13	688983	Screw			
5	8312709	Clip, Console	14	W10773242	Screw			
			15	3348629	Screw			


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10773242	Screw	18		Panel, Front	31	W10869141	Cord, Power
2	3357011	Screw		W10664692	White	32	W10775448	Clip, Front Panel
3	693995	Screw	19	685203	Clip, Felt Pad	33	8066217	Hinge, Top
4	W10841728	Seal, Spill Guard	20	3389441	Assembly, Door Catch	34	691366	Idler Assembly
5	8558833	Cover, Terminal Block	21	W10823580	Seal, Door	35	W10131364	Belt, Drive
6	3404162	Clamp, Motor (With Shield)	22	343641	Screw	36	348780	Base, Motor
7	W11598681	Panel, Rear	23	341029	Clamp, Pipe	37	3400500	Bolt
8	W10575896	Clip, Spring	24	8066056	Hinge, Door (Right)	38	8066184	Pulley, Motor
9	W10569603	Switch, Door		8066057	Hinge, Door (Left)	39	W10396029	Assembly, Motor
10	697773	Screw	25	696144	Strike, Door	40	W10121316	Clamp, Motor Mount
11	342055	Screw	26	695737	Door, Rear	41	W11564940	Burner Assembly (60 Hz) (Type 1)
12	342043	Screw	27		Door, Outer	42	337189	Clip, Hinge
13	W10561321	Foot, Dryer		W10714515	White	43	3357011	Screw
14	W10041960	Spring, Door	28		Handle, Door			
15		Cabinet		W10714516	White			
	8530603	White	29	W10803476	Assembly, Seal and Bearing			
16	98234	Clip, Ground	30		Plug, Hinge Hole			
17	8066092	Lock, Front Top		8564457	White			

BULKHEAD PARTS




BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798023	Assembly, Lint Chute	16	W11050897	Kit, Thermal Cut-Off (Includes Thermostat)	29	W10298789	Nut, Hex
2	489463	Screw	17	3390647	Screw	30	W10714468	Rear Bulkhead
3	3388703	Washer	18	8066049	Funnel, Burner	31	338906	Sensor, Radiant
4	347139	Seal, Lint Chute	19	3403636	Baffle, Drum (Short)	32	692490	Baffle, Drum (Long)
5	90767	Screw	20	90296	Nut, Push On	33	692526	Bearing, Ring
6	W10389567	Shield, Exhaust	21	W11032820	Bracket, Support	34	W10219342	Screw
7	3392519	Fuse, Thermal (91C)	22	W10214261	Socket, Light	35	W10856781	Seal, Rear Drum
8	8578825	Bracket, Drum Light	23	339956	Seal	36	W10757750	Assembly, Drum (Complete)
9	3387134	Thermostat	24	W10512946	Washer, Tri Ring	37	3406124	Bulb, Light
10	694089	Wheel, Blower	25	W10359270	Shaft, Drum Roller - Left Hand Thread	38	3402841	Lens, Drum Light
11	8577230	Housing, Blower	26	W10359269	Shaft, Drum Roller - Right Hand Thread			
12	3398161	Clip, Heater Box	27	3397590	Roller, Support			
13	3390631	Screw	28	348197	Washer			
14	8530285	Box, Heater (96C)						
15	W10754607	Thermostat, High Limit SPST (180F)						

BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11564940	Burner Assembly (60 Hz) (Type 1)	7	693986	Base, Burner	13	326049536	Screw
2	688617	Tube, Burner	8	3387057	Screw			Following Parts Not Illustrated
3	694298	Bracket, Ignitor	9		Orifice, Burner			
4	686590	Ignitor		234826	Type 1 (Natural)	W11581316		Kit, LP Conversion
5	W10366705	Screw	10	W11564943	Valve, Gas (60 Hz)			
6	343641	Screw	11	W10295523	Pipe Plug			
			12	W10328463	Coil (60 Hz)			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

72017	White
-------	-------

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

799344	White (Uncut)
--------	---------------

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

350930	White
350938	Gray Primer

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

279948	Kit, Dryer Repair
3406839	Dry Rack
8522199	Kit, Dryer Vent Testing