## Cooktops approved for installation above wall ovens

Models listed below are partial model numbers only. For the perfect match use the beginning sequence of your model number.

|                          |         | 30" WALL OVENS |         |         |         | 27" WALL OVENS |         |
|--------------------------|---------|----------------|---------|---------|---------|----------------|---------|
|                          |         | CTS90FP        | CTS90DP | CTS70DP | CTS70DM | CKS70DP        | CKS70DM |
| 30" INDUCTION<br>COOKTOP | CHP9530 |                | •       | •       | •       | •              | •       |
| 36" INDUCTION<br>COOKTOP | CHP9536 |                | •       | •       | •       |                |         |
| 30" ELECTRIC<br>COOKTOPS | CEP7030 |                | •       | •       | •       | •              | •       |
|                          | CEP9030 |                | •       | •       | •       | •              | •       |
| 36" ELECTRIC<br>COOKTOPS | CEP7036 |                | •       | •       | •       |                |         |
|                          | CEP9036 |                | •       | •       | •       |                |         |
| 30" GAS<br>COOKTOPS      | CGP7030 |                | •       | •       | •       |                |         |
|                          | CGP9530 |                | •       | •       | •       |                |         |
| 36" GAS<br>COOKTOPS      | CGP7036 |                | ٠       | •       | •       |                |         |
|                          | CGP9536 |                | •       | •       | •       |                |         |