



WCF43S3SD Parts List

No.	Parts#	Parts Name	Qty
1	US3-23	Water tank	1
2	US2-14	Strainer	1
3	US1-32	Power cord	1
4	US1-39	Compressor (ESD60U6)	1
5	US3-14	The cover of Power box	1
6	US5-1	Power PCB	1
7	US3-13	Power box	1
8	US4-101-SR	Upper hinge	1
9	US1-6	The fan of evaporator	1
10	US2-20	Copper Evaporator	1
11	US3-90	Air-duct Board	1
	US4-94	fan net	1
	US4-93	fan net	1
12	US3-86	The carbon filter	1
13	US1-9	The upper sensor	1
14	US3-49	The cover of the sensor	2
15	US1-28-W	Light	2
16	US3-12	Light cover	2
17	US4-102	The middle air-duct upper board	1
18	US5-5	Control PCB	1
19	US3-63	The control panel box	1
20	BZ1-126	Sticker	1
21	MT07-7	Door with handle/gasket	1
22	US4-66-B	The lower supporter of the door	1
23	US3-4	Small shelf	2
24	US3-2	Big shelf	7
25	US4-48	The small rolling guide	4
26	US4-49	The big rolling guide	14
27	US4-103	The middle air-duct lower board	1
28	US1-7	The middle fans	2
29	US1-10	The lower sensor	1
30	US4-105	The front vent (stainless steel)	1
31	US1-17	Heater	1
32	US1-7	Heating fan	1
33	US3-24	Inner water tank	1
34	US4-104	Lower hinger	1
35	US2-17	Condensor	1
36	US4-56	The fix plate	1
37	US3-45	Feet	4
38	US2-11	Circle pipe	1
39	US1-34	Bracket for fan	2
40	US4-52	The fan of condensor	1
41	US4-27	The bottom plate	1