

STREET GLIDE® FAIRING STYLE (Batwing)
REMOVE


Remove fairing to gain access to speakers. Once removed, unplug and remove speakers and mounting ring. Retain factory woven speaker grille.

ADAPTER


Align adapter with factory screw holes and attach with supplied screws. Be sure gasket is properly seated between grille and adapter.

CONNECT


Install speaker using screws supplied with speaker and reattach speaker wires. Be sure to use proper polarity when connecting speaker. Test and reassemble fairing.

ROAD GLIDE® FAIRING STYLE (Shark Nose)
REMOVE


Remove fairing to gain access to speakers. Once removed, unplug and remove speakers.

ADAPTER


Align adapter with factory screw holes and attach with supplied screws. Be sure gasket is properly seated between grille and adapter.

CONNECT


Install speaker using screws supplied with speaker and reattach speaker wires. Be sure to use proper polarity when connecting speaker. Test and reassemble fairing.

Speaker Fitment Guide

PRIME	PUNCH	POWER
--	P16	T16
	P165	T165

...Find Out More About These Products
www.rockfordfosgate.com/products

1010-59672-01
 Rockford Fosgate Arizona, USA

