




ASSEMBLY INSTRUCTIONS
INSTRUCCIONES


2727WH-T-4848 (COUNTER HIGH TABLE)
2727WH-T-4848 (MESA ALTA DE MOSTRADOR)

PARTS LIST
LISTA DE PARTES

1		1PC / PIEZA
2		1PC / PIEZA
3		4PCS / PIEZAS

A		BOLT 5/16"*18*2"	16PCS / PIEZAS
B		SPRING WASHER 5/16"*12mm	16PCS / PIEZAS
C		FLAT WASHER 5/16"*19mm	16PCS / PIEZAS
D		ALLEN WRENCH 4mm	1PC / PIEZA

ASSEMBLY INSTRUCTIONS
INSTRUCCIONES



DO NOT TIGHTEN ALL BOLTS UNTIL COMPLETELY ASSEMBLED.
NO APRETAR LOS TORNILLOS HASTA ARMAR COMPLETAMENTE.