


homestyles[®]

20 05525 0301

Dining Table




IMPORTANT

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.

Part List



C.
Pedestal
1 pc.

For assembly see instructions in carton 20 05525 0302.