



41049 OAKWOOD

Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice.
LHF - left hand facing RHF - right hand facing IA - inside arm to inside



09 Corner Curve
46 x 46 x 41"
117 x 117 x 104cm



10 Armless Chair
24 x 37 x 41"
61 x 94 x 104cm



30 Armless Recliner
24 x 37 x 41"
61 x 94 x 104cm




31 Wallhugger Recliner
Pwr
35 x 37 x 41"
89 x 94 x 104cm
IA: 22" / 56cm



32 Rocker Recliner Chair
35 x 37 x 41"
89 x 94 x 104cm
IA: 22" / 56cm



33 Swivel Recliner Chair
35 x 37 x 42"
89 x 94 x 107cm
IA: 22" / 56cm



Dimensions

- A - Seat Depth - 20" / 51cm
- B - Seat Height - 20" / 51cm
- C - Arm Height - 23.5" / 60cm

Features


- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: 11 or 12 gauge sinuous springs which are engineered to provide lasting comfort and strength
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- Back filled with blown fibre
- Chaise styling for ultimate comfort and support in full recline
- Toggle power mechanism




35 Wallhugger Recliner Chair
35 x 37 x 41"
89 x 94 x 104cm
IA: 22" / 56cm



39 Power Rocker Recliner
35 x 37 x 41"
89 x 94 x 104cm
IA: 22" / 56cm



51 Sofa Recliner
81 x 37 x 41"
206 x 94 x 104cm
IA: 68" / 173cm




53 Loveseat Recliner
59 x 37 x 41"
150 x 94 x 104cm
IA: 46" / 117cm




54 RHF Loveseat Recliner
55 LHF Loveseat Recliner
52 x 37 x 41"
132 x 94 x 104cm



60 Power Armless Recliner
24 x 37 x 41"
61 x 94 x 104cm



61 Power Sofa Recliner
81 x 37 x 41"
206 x 94 x 104cm
IA: 68" / 173cm



63 Loveseat Recliner Power
59 x 37 x 41"
150 x 94 x 104cm
IA: 46" / 117cm



64 RHF Loveseat Recliner Power
65 LHF Loveseat Power Recliner
52 x 37 x 41"
132 x 94 x 104cm



41049 OAKWOOD

Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.

How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty

Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty

5-Seat Corner Curve Reclining Sectional

98 x 98"

249 x 249cm

6-Seat Corner Curve Reclining Sectional

123 x 123"

312 x 312cm