


5979 Westside Sectional | Components & Configurations


Conversation Sofas & Sectionals

Components


LAF = Left-Arm-Facing
RAF = Right-Arm-Facing




5979-33
LAF Corner Sofa




5979-34
RAF Corner Sofa




5979-37
LAF Sofa




5979-38
RAF Sofa




5979-27
LAF Loveseat




5979-28
RAF Loveseat




5979-29
Armless Loveseat




5979-23
Full Wedge




5979-231
Corner Chair




5979-25
LAF Chaise




5979-26
RAF Chaise



5979-17
LAF Chair



5979-18
RAF Chair



5979-19
Armless Chair

Scale 1/4" = 1'

Dimensions are in inches and are subject to variance.
© Flexsteel Industries, Inc. 10/14 • Rev. 4/17
FLX-FR5979-CC-PP









FLEXSTEEL[®]
HOME

5979 Westside Sectional | Components & Configurations

Conversation Sofas & Sectionals

Sample Configurations



Scale 1/4" = 1'

Dimensions are in inches and are subject to variance.
© Flexsteel Industries, Inc. 10/14 • Rev. 4/17
FLX-FRS979-CC-PP



FLEXSTEEL[®]
HOME