

homestyles®

20 05533 0552


## Bunk Bed

### IMPORTANT


Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.




### Part List



D.  
Upper End Panel  
1 pc.



E.  
Upper End Panel  
1 pc.



F.  
Upper Slats  
1 pc.

For assembly see instructions in carton 20 05533 0553.

Home Styles Customer Service: [www.homestyles-furniture.com](http://www.homestyles-furniture.com),  
[servicedesk@homestyles-furniture.com](mailto:servicedesk@homestyles-furniture.com), 888-680-7460, 877-831-0319