


Pedestal Desk




IMPORTANT

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.


Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.

Part List



A.
Top
1 pc.



L.
Keyboard
1 pc.




M.
Keyboard Rail
1 pc.




K.
Keyboard
1 pc.




N.
Keyboard Rail
1 pc.




P.
Keyboard Box
1 pc.



Q.
Keyboard Box
1 pc.




O.
Keyboard Support
1 pc.



W.
Metal Strip
2 pcs.

Hardware List



Hex Wrench
1 pc.




Cam Lock Screw
48 pcs. (+2 extra)



M3.5x25
Wood Screw (long)
36 pcs. (+1 extra)




M3.5x25
Tapered
Wood Screw (long)
8 pcs. (+1 extra)



Magnet
1 pc.



Adjustable Pin
4 pcs. (+1 extra)



Knob
7 pcs.



Small Hex Wrench
1 pc.



Cam Lock
48 pcs. (+6 extra)



M3.5x13
Wood Screw (short)
16 pcs. (+1 extra)



M3.5x10
Tapered
Wood Screw (short)
6 pcs. (+1 extra)



M3x13
Wood Screw
for Magnet
2 pcs. (+1 extra)



M6x35
Head Cap Bolt
8 pcs. (+1 extra)



M4x15
Machine Screw
7 pcs.

For assembly see instructions in carton 88 5531 182.