
BOX OF TV STAND

ITEM	DRAWING	DESCRIPTION	QTY
A		TV STAND	1





THE ANTI TIPPING HARDWARE IS LOCATED IN THE RIGHT SIDE BOTTOM DRAWER OF THE TV STAND.

NOTE: MUST TIGHTEN SCREWS PERIODICALLY. WITH USE SCREW MAY BECOME LOOSE. CHECK TIGHNESS OF ALL SCREW EVERY 6-8 WEEKS.

CLEANING INSTRUCTION