



19  
233  
59M  
59

57H  
58H  
58L  
57L  
58M  
58  
57M  
57

**FEATURES**

**Flexsteel Spring Unit**

- 
- 

DualFlex

**Back Construction**

- 
- 

Attached

**Seat Construction**

- 
- 

Attached

**Seat Cushion(s)**

- 
- 

High-Density (HC)

**Tailoring**

- 

Arm Covers

- Standard
- Optional

**PRODUCT DIMENSIONS**

	OVERALL			SEAT			Arm Height	Open Depth	Wall Clearance
	Height	Width	Depth	Height	Width	Depth			
<b>Straight Console</b> -72	43"	8"	36"	24"	8"	22"			
<b>Armless Chair</b> -19	44"	26"	42"	21"	26"	23"			
<b>LAF Power Recliner with Power Headrest</b> -57H	43"	32"	42"	20"	24"	22"	26"	70"	5"
<b>RAF Power Recliner with Power Headrest</b> -58H	43"	32"	42"	20"	24"	22"	26"	70"	5"
<b>Full Wedge</b> -233	43"	65"	42"	20"	42"	25"			
<b>Armless Power Recliner</b> -59M	43"	26"	42"	20"	26"	22"		70"	5"
<b>RAF Power Recliner with Power Headrest &amp; Lumbar</b> -58L	43"	32"	42"	20"	24"	22"	26"	70"	5"
<b>LAF Power Recliner with Power Headrest &amp; Lumbar</b> -57L	43"	32"	42"	20"	24"	22"	26"	70"	5"
<b>Armless Recliner</b> -59	43"	26"	42"	20"	26"	22"		70"	5"
<b>RAF Power Recliner</b> -58M	43"	32"	42"	20"	24"	22"	26"	70"	5"
<b>RAF Recliner</b> -58	43"	32"	42"	20"	24"	22"	26"	70"	5"
<b>LAF Power Recliner</b> -57M	43"	32"	42"	20"	24"	22"	26"	70"	5"
<b>LAF Recliner</b> -57	43"	32"	42"	20"	24"	22"	26"	70"	5"

**NOTES**

Transitional style  
Available in over 250 select fabrics  
Upholstery Material: Fabric  
Power button includes a USB port  
Console includes storage compartment and two cupholders  
Removable backs allow for easy lifting and maneuvering through doorways  
Power allows you to smoothly recline to any position and adjust the headrests.  
On styles with arms, a home feature returns the headrest and footrest to their original positions.  
A single USB port is included on each power button control on styles with arms.  
Power to the USB port is activated only when the port is in use.  
Power allows you to smoothly recline to any position.  
Power allows you to smoothly recline to any position, adjust the headrests, and adjust the lumbar supports.  
On styles with arms, a home feature returns the headrest, footrest, and lumbar support to their original positions.



**Power Recline & Headrest**




**Hidden Power Button Control**

The power button control is located discreetly between the seat and arm for convenient operation.





Power Recline,  
Headrest, & Lumbar









**Interlocking Brackets**  
Interlocking brackets securely  
attach one sectional component  
to another to prevent them from  
separating even when reclining.

# 2810 Arlo Sectional | Components & Configurations





## Reclining Sofas & Sectionals

### Components

LAF = Left-Arm-Facing  
 RAF = Right-Arm-Facing



### Sample Configurations



Scale 1/4" = 1'

Dimensions are in inches and are subject to variance.  
 © Flexsteel Industries, Inc. 12/20  
 FLX-CP-FR-CC-2810

