



Please read this manual carefully before operating your set and retain it for future reference. To view the instructions of advanced features, visit <a href="http://www.lg.com">http://www.lg.com</a> and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL



www.lg.com Copyright © 2018 LG Electronics Inc. All Rights Reserved. **WARNING:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. **Wash hands after handling.** 

#### FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.


This equipment should be installed and operated with minimum distance 20 cm (7.8 inches) between the antenna and your body. Users must follow the specific operating instructions for satisfying RF exposure compliance.

#### FCC Radio Frequency Interference Requirements:

High power radars are allocated as primary users of the 5.25 to 5.35 GHz and 5.65 to 5.85 GHz bands. These radar stations can cause interference with and/or damage this device. This device cannot be co-located with any other transmitter.

#### Responsible Party:

LG Electronics USA, Inc. 1000 Sylvan Avenue Englewood Cliffs, NJ 07632 Tel: 1-800-243-0000





LG Customer Information Center		
1-800-243-0000 1-888-865-3026	USA, Consumer USA, Commercial	
Register your product Online!		
www.lg.com		

Printed in China

SK6Y.DUSALLK\_SIM\_MFL70540850.indd 1,4



Subwoofer Connection

Place the wireless subwoofer near the sound bar and

1 Connect the power cord of the sound bar and the

**automatically** connected. The subwoofer's green

3 The sound bar and wireless subwoofer will be

wireless subwoofer to the outlet.

Manually Subwoofer Connection

subwoofer blinks quickly.

hold the Pairing button.)

subwoofer turns on.

2 Turn on the sound bar.

**3** Pairing is completed.

If the subwoofer does not make sound, try to

1 Press Pairing button on the rear of the wireless

The green LED on the rear of the wireless

(If the green LED does not blink, press and

• The green LED on the rear of the wireless

Keep the sound bar and the subwoofer

prevent wireless interference.

away from the device (ex. wireless router,

microwave oven, etc.) over 1 m (3.3 ft) to

follow steps below.


2 Turn on the sound bar.

LED turns on.

connect manually.

subwoofer.

#### Front Panel




(Standby) · · · · · · · Switches the unit ON or OFF. **F** (Function) · · · · · · Selects function **─/+** (Volume) · · · · · · · Adjusts volume Selects Wi-Fi function.

### LED indicator: Shows connection status.

- White (Blinking): Waiting for network connection on Wi-Fi function.
- White (Staying on): Network connection is completed on Wi-Fi function or the other functions are selected.
- White (Dimmed): Standby mode with network connection.
- Red (Staying on): Standby mode without network connection.

#### **Rear Panel**




..... AC adapter input OPTICAL IN .....Connect to an optical device. PORTABLE IN ..... Connect portable device. USB (Service only) ......S/W download connector. ·····Connect to router. HDMI IN .....Connect to device with HDMI OUT. **HDMI OUT (TV ARC)**····· Connect to a TV.

# TV Connection

Connect the sound bar and TV using Optical (A) or HDMI ARC (B).

## Optical Connection

- 1 Connect the sound bar to the TV using Optical
- 2 Set up [External Speaker (Optical)] on your TV setting menu.




## HDMI(ARC) Connection

- 1 Connect the sound bar to the TV using HDMI
- 2 Set up [External Speaker (HDMI ARC)] on your TV setting menu.



- HDMI connection is unavailable if your TV does not support HDMI ARC.
- If this unit is connected by OPTICAL and ARC at the same time, the ARC signal is a high priority.

## Additional Device Connection



2 Set the input source by pressing **F** on the remote control or unit repeatedly.

#### **Network Connection**



- 1 Check network condition. A router connected to network should be installed.
- 2 Connect your smart device to your home network.
- 3 Connect the sound bar to the power supply.

All devices should be connected to same router.

## Download LG Wi-Fi Speaker Application

Download "LG Wi-Fi Speaker" on the App Store or Google Play Store.




## Launch LG Wi-Fi Speaker App

Follow the steps for wired or wireless connection displayed on the screen.

#### Remote control





**SOUND EFFECT:** Selects a sound effect mode.

Adjusts sound level of each speaker.

**AV SYNC:** Synchronizes the audio and video.

(i): Displays the input source information. AUTO VOL: Adjusts too loud or low output volume level appropriately.

AUTO POWER: Automatically turns on by an input

## Additional Information

## Specification

(i) AUTO AUTO POWER

Power consumption	Refer to the main label.
AC adapter	Model: DA-38A25 Manufacturer: Asian Power Devices Inc. Input: 100 - 240 V ~ 50 - 60 Hz
	• Output : 25 V === 1.52 A
Dimensions (W x H x D)	Approx. 1061.0 mm x 57.5 mm x 87.0 mm (41.8 inch x 2.3 inch x 3.4 inch)
Amplifier (Total RMS Output power)	360 W RMS

Design and specifications are subject to change without notice.

## Rear Speakers Ready

Ready for surround sound with Rear Speakers Kit sold separately. (SPK8-S)

#### OPEN SOURCE SOFTWARE NOTICE INFORMATION

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit http://opensource.lge.com. In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com.

This offer is valid for a period of three years after our last shipment of this product. This offer is valid to anyone in receipt of this information.







SK6Y.DUSALLK\_SIM\_MFL70540850.indd 5-8 2018-04-18 9:01:38