

SHARP®

Simply Better Living



SMC1449FS 1.4 CU.FT. SMART MICROWAVE

Alexa Command List

SMC1449FS ALEXA COMMAND LIST

With the Amazon Alexa App or an Echo device you can enjoy hands-free cooking with over 70 Alexa voice commands.

MENU ITEM	COMMAND	QUANTITY RANGE
+ 30 Seconds	Alexa, add 30 seconds to the microwave.	100% Power
Add Time	Alexa, add X minutes to the microwave. Alexa, add Y seconds to the microwave.	X = 01:00 - 60:00 Y = 00:01 - 00:59
Pause Time	Alexa, pause the microwave.	-
Resume Time	Alexa, resume the microwave.	-
Stop Time	Alexa, stop the microwave.	-
Time Cook	Alexa, microwave for X minutes and Y seconds. Alexa, cook for X minutes and Y seconds. Alexa, reheat for X minutes and Y seconds.	X = 01:00 - 60:00 Y = 00:01 - 00:59
Meat (Auto Defrost)	Alexa, defrost. Alexa, defrost meat. Alexa, defrost X pounds of meat.	X = 1.0 / 1.5 / 2.0 / 2.5 lb
Poultry (Auto Defrost)	Alexa, defrost poultry. Alexa, defrost X pounds of poultry.	X = 1.5 / 2.0 / 2.5 / 3.0 lb
Seafood (Auto Defrost)	Alexa, defrost seafood. Alexa, defrost X pounds of seafood.	X = 0.5 / 1.0 / 1.5 / 2.0 lb
Time Defrost	Alexa, defrost for X minutes. Alexa, defrost for Y seconds.	X = 01:00 - 60:00 Y = 00:01 - 00:59

SMC1449FS ALEXA COMMAND LIST CONT.

MENU ITEM	COMMAND	QUANTITY RANGE
Time Cook	Alexa, microwave/cook for X minutes / seconds at power level Y.	X = 00:01 - 60:00 Y = 1 - 10
Beverage	Alexa, microwave/cook beverage. Alexa, microwave/cook X cups of beverage.	X = 1 / 2 / 3 cups
Popcorn	Alexa, microwave/cook popcorn. Alexa, microwave/cook X popcorn.	X = Single / Classic
Potato	Alexa, microwave/cook potato.	-
Frozen Entrée	Alexa, microwave/cook frozen entrée.	-
Frozen Vegetables	Alexa, microwave/cook frozen vegetables.	-
Melt/Soften - Butter	Alexa, melt/soften butter.	-
Melt/Soften - Chocolate	Alexa, melt/soften chocolate.	-
Melt/Soften - Ice Cream	Alexa, melt/soften ice cream.	-
Melt/Soften - Cheese	Alexa, melt/soften cheese.	-
Asparagus	Alexa, microwave/cook asparagus.	-
Beans	Alexa, microwave/cook beans.	-
Beets	Alexa, microwave/cook beets.	-
Broccoli	Alexa, microwave/cook broccoli.	-
Brussel Sprouts	Alexa, microwave/cook brussel sprouts.	-
Butternut Squash	Alexa, microwave/cook butternut squash.	-
Cabbage	Alexa, microwave/cook cabbage.	-

SMC1449FS ALEXA COMMAND LIST CONT.

MENU ITEM	COMMAND	QUANTITY RANGE
Carrots	Alexa, microwave/cook carrots.	-
Casserole	Alexa, reheat casserole.	-
Cauliflower	Alexa, microwave/cook cauliflower.	-
Chicken	Alexa, reheat chicken. Alexa, reheat X oz of chicken.	X = 5.0 / 10.0 / 15.0 / 20.0 oz
Chicken - Tenders	Alexa, reheat chicken tenders. Alexa, reheat X chicken tenders.	X = 4 -12
Chicken - Wings	Alexa, reheat chicken wings. Alexa, reheat X chicken wings.	X = 4 - 12
Chowder	Alexa, reheat chowder.	-
Corn	Alexa, microwave/cook corn.	-
Dinner Plate	Alexa, reheat dinner plate.	-
Dumplings	Alexa, reheat dumplings.	-
Eggplant	Alexa, microwave/cook eggplant.	-
Fish	Alexa, microwave/cook fish.	-
Fishsticks	Alexa, reheat fishsticks. Alexa, reheat X fishsticks.	X = 4 - 12
Hotdogs	Alexa, reheat hotdogs. Alexa, reheat X hotdogs.	X = 1 / 2
Kale	Alexa, microwave/cook kale.	-

SMC1449FS ALEXA COMMAND LIST CONT.

MENU ITEM	COMMAND	QUANTITY RANGE
Leftovers	Alexa, reheat leftovers.	-
Mac and Cheese	Alexa, reheat mac and cheese.	-
Meatballs	Alexa, reheat meatballs.	-
Meatballs - Chicken	Alexa, reheat chicken meatballs.	-
Meatballs - Turkey	Alexa, reheat turkey meatballs.	-
Mozzarella Sticks	Alexa, reheat mozzarella sticks. Alexa, reheat X mozzarella sticks.	X = 4 - 12
Mushrooms	Alexa, microwave/cook mushrooms.	-
Oatmeal	Alexa, reheat oatmeal.	-
Onions	Alexa, microwave/cook onions.	-
Parsnips	Alexa, microwave/cook parsnips.	-
Pasta	Alexa, reheat pasta.	-
Peas	Alexa, microwave/cook peas.	-
Peppers	Alexa, microwave/cook peppers.	-
Pork Chops	Alexa, reheat pork chops. Alexa, reheat X oz of pork chops.	X = 8.0 / 16.0 / 24.0 / 32.0 oz
Potato - Wedges	Alexa, reheat potato wedges. Alexa, reheat X oz of potato wedges.	X = 4 - 8 oz
Quinoa	Alexa, reheat quinoa.	-
Rice - Brown	Alexa, reheat brown rice.	-

SMC1449FS ALEXA COMMAND LIST CONT.

MENU ITEM	COMMAND	QUANTITY RANGE
Rice - White	Alexa, reheat white rice.	-
Salmon	Alexa, microwave/cook salmon.	-
Shrimp	Alexa, microwave/cook shrimp.	-
Soup	Alexa, reheat soup.	-
Spinach	Alexa, microwave/cook spinach.	-
Squash	Alexa, microwave/cook squash.	-
Stir Fry	Alexa, reheat stir fry.	-
Tilapia	Alexa, microwave/cook tilapia.	-
Tomatoes	Alexa, microwave/cook tomatoes.	-
Tuna	Alexa, microwave/cook tuna.	-
Turnips	Alexa, microwave/cook turnips.	-
Vegetables	Alexa, microwave/cook vegetables.	-
Vegetables - Mix	Alexa, microwave/cook mix vegetables.	-
Zucchini	Alexa, microwave/cook zucchini.	-

Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. and its affiliates

© 2020 Sharp Electronics Corporation. All rights reserved.

Sharp and all related trademarks are trademarks or registered trademarks of Sharp Corporation and/or its affiliated companies. All other trademarks are property of their respective owners.

QUESTIONS?

1.800.BE.SHARP

SIMPLY BETTER LIVING

At Sharp Home Electronics Company of America, we are committed to Simply Better Living. Our innovative home appliance products are SIMPLE to use, BETTER than the competition, and encourage a HEALTHY LIFESTYLE.

SHARP ELECTRONICS CORPORATION
100 Paragon Drive, Montvale NJ, 07645
1.800.237.4277 • www.sharpusa.com



SHARP

Be Original.