Assembly Instruction for


THREE PACK OCCASIONAL SET CSD100OT/CSD100OTE

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

- We recommend that you should assemble this product with the assistance of another person; this
 will make assembly easier, and will help to eliminate damage the product or injury to persons
 during assembly.
- 2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
- 3. Please do not over tighten screws or bolts .
- 4. Please put all parts on a non abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


PARTS LIST							
N <u>o</u>	PARTS DESC.		CODE.	Q'TY.			
A	0	COFFEE TABLE TOP FRAME	PCSD 100CTTOP1	1PC			
В		COFFEE TABLE TOP GLASS	PCSD100 CTTOP2	1PC			
С	A	COFFEE TABLE CENTER LEG	PCSD100 CTLEG1	1PC			
D		COFFEE TABLE SIDE LEG	PCSD100 CTLEG2	2PCS			
Е		AND TABLE TOP FRAME	PCSD 100ETTOP1	2PCS			
F	0	AND TABLE TOP GLASS	PCSD100 ETTOP2	2PCS			
G	N	AND TABLE CENTER LEG	PCSD100 ETLEG1	2PCS			
Н	D	AND TABLE SIDE LEG	PCSD100 ETLEG2	4PCS			

HARDWARE LIST							
N <u>o</u>	HARDWARE DESC.		CODE.	Q'TY.			
1	9	BOLT 1/4"x 55mm		2PCS			
2	Ø			6PCS			
3	0	FLAT WASHER Ø1/4" Ø20x2mm	PCSD 100OTHW	6PCS			
4		ALLEN KEY 2-1/4"x4mm		1PC			
5	0 03 100	LOMBINER Ø7x35mm		12PCS			
6	977	NUT Ø15x12mm		12PCS			
7	4	RUBBER PLUG		12PCS			
8		WOOD TENON Ø8x30mm		20PCS			
9	0	GLUE		1PC			
10	9	BOLT 1/4"x 32mm		4PCS			



Assembly Instruction for

THREE PACK OCCASIONAL SET CSD100OT/CSD100OTE




MADE IN VIETNAM

PAGE 2 OF 3

Assembly Instruction for

THREE PACK OCCASIONAL SET CSD100OT/CSD100OTE



STEP 6

