

UTTERMOST

ASSEMBLY INSTRUCTIONS

22540

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

We suggest a licensed electrician for all fixture installations

Installation Steps

1. Carefully unpack your new fixture and lay out all the parts on a clear surface.
2. Thread the Mounting screws into the matching holes of the Mounting bar, and tighten with the Hex nut. Thread the Ground screw into the hole of the Mounting bar. Secure the Mounting bar to the outlet box with the Outlet box screws.
3. Make Wire connections with Wire Connector:
 - The smooth wire (w/ marking) from fixture to Black Wire from power source.
 - The ribbed wire (w/o marking) from Fixture to White Wire from power source.
 - Attach the Ground Wire and house ground wire to the Mounting bar with the green Ground screw.

Carefully tuck wires back into the Outlet Box.

4. Place the fixture Back plate over the two Mounting screws so they protrude through the holes in the Back plate. Thread the Ball nut onto the Mounting screws and continue turning until the fixture is snug against the ceiling.
5. Install the Glass panel into the frame then secure by pressing down the clip.
6. Install the candle cover over the socket.

DO NOT EXCEED THE MAXIMUM WATTAGE RATING!

7. Turn on the power at fuse or Circuit Box.

