

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



ITEM: **182104**




ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!
1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

PAGE 2 OF 15

ITEM: 182104							
S	RIGHT BACK LEG		1 PC	т	FOOTREST		1 PC
z HARDWARE IDENTIFICATION							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	12	SUPPORT PLATE SR	000	2 PCS
2	WOODEN DOWEL Ø8x30mm		58 PCS	13	SCREW Ø4x15mm SR		16 PCS
3	CAM BOLT Ø7x35.5mm SR		38 PCS	14	FOOTREST SUPPORT LEG Ø25mm BLK	é de	3 PCS
4	CAM LOCK Ø15x12mm SR	A DAY	60 PCS	15	SUPPORT LEG 129mm BLK		2 PCS
5	SCREW Ø4.5x42mm SR	AUTUUL (B	8 PCS	16	SCREW Ø4x15mm BLK		4 PCS
6	WOODEN DOWEL Ø8x50mm		16 PCS	17	FLOOR PROTECTOR 38x38mm		4 PCS
7	CAM BOLT Ø7x31.5mm BLK		22 PCS	18	FLOOR PROTECTOR 18x18mm		2 PCS
8	BOLT M6x38mm BLK		4 PCS	19	FLOOR PROTECTOR Ø25mm		5 PCS
9	BOLT M6x15mm BLK		6 PCS	20	SCREW DRIVER	•	1 PC
10	ALLEN WRENCH 4mm SR	F	1 PC	21	STICKER Ø20mm		10 PCS
11	GLASS HOLDER		2 PCS				
Z11,Z14,Z15 not included in blister packaging.							
NOTE: Philling head screw driver is required in the assembly process: however, manufacturer does not provide this item							

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

PAGE 3 OF 15

