



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

306071P
Wall Bed Panels

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!








- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.








ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	RIGHT BED PANEL		1PC	BD	BED FROM BOX		1 SET
B	LEFT BED PANEL		1PC		306070 Q or 306070 KE		1 SET
C	LEG		2PCS				


HARDWARE IDENTIFICATION

1	ALLEN WRENCH (5MM-RBW)		1PC	2	FLAT WASHER (Ø 5/16 "-RBW)		14PCS
3	SHORT BOLT (Ø 5/16 "X32mm-RBW)		12PCS	4	LOCK WASHER (Ø 5/16 "-RBW)		14PCS
5	LONG BOLT (Ø 5/16 "X60mm-RBW)		2PCS				


ITEM: **306071P**

ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2



STEP 3





ITEM: **306071P**

ASSEMBLY INSTRUCTIONS


STEP 4

COMPLETE



ITEM: 306071P

COASTER®
FINE FURNITURE



NOTE: Dimension tolerance $\pm 5\%$