

### ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

# 721373 3PC Occasional Set

#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

Remove hardware from box and sort by size.
 Please check to see that all hardware and parts are present prior to start of assembly.

3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

#### PARTS INDENTIFICATION


No	DESCRIPTION & FIGURE	QTY
	END TABLE TOP	
А		2pcs
В	END TABLE LEG	8pcs
С	END TABLE LEG SUPPORT 1	8pcs
D	END TABLE LEG SUPPORT 2	8pcs
E	COFFEE TABLE TOP	1pc
F	COFFEE TABLE LEG	4pcs
G	COFFEE TABLE SHORT LEG SUPPORT 1	2pcs
Н	COFFEE TABLE SHORT LEG SUPPORT 2	2pcs
ı	COFFEE TABLE LONG LEG SUPPORT 1	2pcs
J	COFFEE TABLE LONG LEG SUPPORT 2	2pcs
K	COFFEE TABLE SUPPORT CROSSBAR	2pcs

#### HARDWARE PACKAGE:

No	DESCRIPTION	FIGURE	QTY
1	BOLT	<b>ூ</b> M6×12mm	72pcs
2	BOLT	<b>⑥</b> ))))))))))))))))))))))))))))))))))))	8pcs
3	ALLEN KEY (4mm)		1pc




#### STEP 1





#### STEP 2






PAGE 3 OF 6


COASTERFURNITURE.COM




#### STEP 3



#### STEP 4








# COASTER


### STEP 7


#### COMPLETE











Note: Dimension tolerance ± 5%