


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

736002
TV CONSOLE

ITEM:736002



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

50 MINUTES

MAX TV SIZE : 64"


PARTS IDENTIFICATION

A LEFT SIDE
PANEL




1 PC

B RIGHT SIDE
PANEL




1 PC

C DIVIDER PANEL




2 PCS

D BOTTOM PANEL




1 PC

E ADJUSTABLE
SHELF




3 PCS

F TOP PANEL




1 PC

G CROSS BRACE




1 PC

H MIDDLE BACK
PANEL




1 PC

I BACK PANEL



2 PCS

J DOOR















2 PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **736002****HARDWARE IDENTIFICATION****Z**

| NO | DESCRIPTION | FIGURE | Q'TY | NO | DESCRIPTION | FIGURE | Q'TY |
|----|--------------------------|---|--------|----|----------------------------|---|--------|
| 1 | GLUE 15g |  | 1 PC | 7 | PLASTIC FEET Ø15mm |  | 6 PCS |
| 2 | WOODEN DOWEL Ø8x30mm |  | 20 PCS | 8 | HANDLE |  | 2 PCS |
| 3 | CAM BOLT Ø7x35.5mm SR |  | 14 PCS | 9 | HANDLE BOLT Ø4x25mm BLK |  | 2 PCS |
| 4 | CAM LOCK Ø15x12mm SR |  | 14 PCS | 10 | HINGE Ø35mm SR |  | 4 PCS |
| 5 | BOLT Ø9.5x55mm SR |  | 4 PCS | 11 | HINGE SCREW Ø4x15mm SR |  | 16 PCS |
| 6 | PIN Ø4.9x8mm SR |  | 12 PCS | 12 | STICKER Ø20mm |  | 3 PCS |


Z10 not included in blister packaging.**NOTE:**

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: **736002**

COASTER
FINE FURNITURE

STEP 1





STEP 2





ITEM: **736002**

STEP 3


COASTER
FINE FURNITURE



STEP 4




Apply glue on all wooden dowels to ensure integrity of the structure.




ITEM: **736002**

COASTER
FINE FURNITURE

STEP 5




STEP 6







ITEM: **736002**

STEP 7



STEP 8





Apply glue on all wooden dowels to ensure integrity of the structure.



ITEM: **736002**

STEP 9

COASTER
FINE FURNITURE






STEP 10





ITEM: **736002**



COASTER
FINE FURNITURE

STEP 11



STEP 12
COMPLETE





Note : Dimension tolerance $\pm 5\%$