



















Components and Hardware List

Top Assembly	Side Frame	Stretcher 1	 #12150 Rectangle Dining Table		
 (A) 1 pc.	 (B) 2 pcs.	 (C) 4 pcs.			
Bottom Stretcher  (D) 1 pc.	M5/16" x 1-1/2" Allen Head Bolt  (E) 10 pcs.	M5/16" x 1-3/4" Allen Head Bolt  (F) 4 pcs.	M5/16" x 4-1/2" All-Thread Bolt  (G) 2 pcs.	5/16"x12*3mm Spring Washer  (H) 16 pcs.	
5/16" x 19*2mm Flat Washer  (I) 14 pcs.	Ø5/16" x 12 Hex Nut  (J) 2 pcs.	Curved Washer 32L x 13 x 8mm  (K) 2 pcs.	5mm Allen Wrench  (L) 1 pc.	12mm Open Wrench  (M) 1 pc.	

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.





To position the table top extensions, grasp the extension by the finger grooves located under each extension and pull outward until the extension stops, lift the extension upward until the top surfaces are level, push inward until there is no gap between the top and extension.