



Position ID	Spare part number.	Replacement	Description
0401	00778426		Housing part
0402	00778424		Housing part
0403	00607781		Screw
0404	00479379		Panel side
0405	00479374		Rail
0406	00758150		Door latch
0406	10005636		Cable harness
0407	00752362		Top left hinge + cable harness
0408	00777836		air passage, upper, stainless steel
0409	00479385		Panel
0410	00635102		Door hinge
0411	00636117		Panel
0412	00479392		air passage, lower, stainless steel
0413	00752760		Lock
0413	12028940		Cable
0415	00479377		left, stainless steel, Gaggenau 30"
0416	00479391		Gaggenau 30"
0417	00479394		Sealing
0418	00607782		Screw-set
0421	10008660		Holder
8001	00707217		Seating
8003	17001373		Grill tray
8004	00778412		Wire Rack for Broil Pan
8431	18043883		Instruction Manual Gaggenau
8432	18043884		Instruction Manual Gaggenau
8433	18043885		Instruction Manual Gaggenau

8461	18043893		Installation Instructions Gaggenau
8512	00460770		Cleaning Cloth
8501	00311859		Oven Cleaning Gel
8502	00311860		Cleaning gel spray for ovens
8506	00311908		Degreaser
8003	00687055	17001373	Grill tray
8509	00466148		Microfiber E-Cloths