





Examine all packaging material for small parts that may have come loose during shipment. Periodic checks are recommended to insure that all components are in proper position, tight and free from damage. Keep this assembly instruction for future reference. Adult assembly is required. The product of Hillsdale Furniture, LLC is designed for residential use only. Customer Service Phone Number: 502-562-0000

HARDWARE LIST

- A (8) M6 x 50mm Allen Bolts
- B (8) Spring Washers
- C (8) Flat Washers
- D (1) Allen Wrench

PARTS LIST

- E (1) Cushion Seat
- F (4) Leg Panels

PART	QTY	HARDWARE	PART	QTY	HARDWARE
A	8		B	8	
C	8		D	1	

STEP 1

Begin assembly by turning the Cushion Seat (E) upside down on a clean smooth surface. Attach each Leg Panel (F) to the Cushion Seat (E) by using 2 Allen Bolts (A), 2 Spring Washers (B) and 2 Flat Washers (C). Tighten all bolts with the Allen Wrench (D) provided. The assembly is now complete.

