


ASSEMBLY INSTRUCTIONS.

SIERRA DINING TABLE

FR-1017-23



THANK YOU FOR YOUR PURCHASE!


PARTS AND HARDWARE.

PARTS LIST

| NO. | DESCRIPTION | IMAGE | Q'TY | | |
|-----|-----------------|------------|------|--|--|
| P1 | TABLE TOP | | 1 | | |
| P2 | LEGS FRAMES | \diamond | 2 | | |
| P3 | STRETCHER FRAME | + | 1 | | |

HARDWARE LIST

| NO. | DESCRIPTION | IMAGE | Q'TY | |
|-----|--------------|-------|------|--|
| H1 | BOLT M8x40 | 9 | 4 | |
| H2 | BOLT M8x50 | | 8 | |
| Н3 | ALLEN KEY M4 | | 1 | |
| | | | | |






NOTES.

Thank you for purchasing this quality product! Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipping.

CAUTION: The item is heavy, assembly should be performed by two people.



(P1