

■ Order by Part Number


Stopper - Polished Stainless

1011



Removable Splash Guard

1016



Sink Flange - Polished Stainless

1017



Mounting Assembly Kit - 1824

Fiber Gasket



Backup Flange



Screws (x3)



Mounting Ring



Snap Ring



Cushion Mount



Lower Mounting Ring




Drain Elbow Kit - 1026

Rubber Gasket

Screws

Drain Elbow



Replacement Power Cord Kit

1024



Garbage Disposals

MODEL

GX100c

Other Available Accessories



Air Switch Remote Controller

- Installs into existing sink hole to operate disposer with plunger air switch.
- Perfect application for island countertops or where electrical switch is unavailable.
- No wiring connections or code restrictions.

Air Switch Base Unit

Air Switch Remote Controller	ARC-4200
Additional Air Switch Button Finish Options:	
Chrome	AS-4201-CH
Satin Nickel	AS-4201-SN
Mediterranean Bronze	AS-4201-BRB
Polished Brass	AS-4201-BR
White	AS-4201-WH
Almond	AS-4201-AL
Biscuit	AS-4201-BIS
Matte Black	AS-4201-BL
Brushed Gold	AS-4201-BG
Polished Nickel	AS-4201-NL

Optional:

Dishwasher Connector Kit

1023



Unjamming Wrench

1037

