

Dimensions

A - Seat Depth - 21" / 53cm B - Seat Height - 20" / 51cm C - Arm Height - 24.5" / 62cm


Features

- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: 11 or 12 gauge sinuous springs which are engineered to provide lasting comfort and strength
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- High resilience seat foam for superior durability and comfort
- Back filled with blown fibre

77500 CORISSA



Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice. LHF - left hand facing RHF - right hand facing IA - inside arm to inside



01 Sofa 91 x 37 x 36" 231 x 94 x 91cm IA: 77" / 196cm



10 Armless Chair 23 x 37 x 36" 58 x 94 x 91cm



22 Sofabed 60" 91 x 37 x 36" 231 x 94 x 91cm IA: 77" / 196cm



74 Rectangle Ottoman 37 x 23 x 17" 94 x 58 x 43cm



02 Chair 23 x 37 x 36" 58 x 94 x 91cm



11 Corner Square 37 x 37 x 36" 94 x 94 x 91cm



23 Angled Ottoman 32 x 32 x 17" 81 x 81 x 43cm



83 Wedge Seat 22 deg. 85 Wedge Seat 45 deg. 23 x 37 x 36" 58 x 94 x 91cm



03 Loveseat 65 x 37 x 36" 165 x 94 x 91cm IA: 51" / 130cm



13 RHF Sofa 12 LHF Sofa 73 x 37 x 36" 185 x 94 x 91cm



27 RHF Sofabed 54" 26 LHF Sofabed 54" 73 x 37 x 36" 185 x 94 x 91cm




42 x 37 x 36" 107 x 94 x 91cm



04 Ottoman 23 x 23 x 17" 58 x 58 x 43cm



14 Armless Loveseat 45 x 37 x 36" 114 x 94 x 91cm



40 RHF Sofa Split 39 LHF Sofa Split 86 x 37 x 36" 218 x 94 x 91cm



89 RHF Chair 88 LHF Chair 28 x 37 x 36" 71 x 94 x 91cm



08 RHF Loveseat 07 LHF Loveseat 51 x 37 x 36" 130 x 94 x 91cm



15 RHF Chaise 16 LHF Chaise 28 x 62 x 36" 71 x 157 x 91cm



56 RHF Armless Chair 55 LHF Armless Chair 23 x 37 x 36" 58 x 94 x 91cm



95 Chair w/Two Arms 38 x 37 x 36" 97 x 94 x 91cm IA: 25" / 64cm



09 Corner Curve 47 x 47 x 36" 119 x 119 x 91cm



19 RHF Bumper 20 LHF Bumper 55 x 42 x 36" 140 x 107 x 91cm



64 Angled Storage Ottoman 44 x 29 x 17" 112 x 74 x 43cm



98 RHF Angled Loveseat 97 LHF Angled Loveseat 66 x 40 x 36" 168 x 102 x 91cm



How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty


Seat Cushion Foam and Fibre-filled **Components** - five year pro-rated warranty


77500 CORISSA





Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.









6-Seat Corner Sectional

111 x 86"

282 x 218cm

79 x 62" 201 x 157cm

3-Seat Sofa Sectional with Chaise 5-Seat Corner Sectional 88 x 86"

224 x 218cm





5-Seat Corner Curve Sectional

6-Seat Corner Curve Sectional with 6-Seat Angled Wedge Sectional Chaise

120 x 98"

305 x 249cm

142 x 49"

361 x 124cm

4-Seat Angled Wedge Corner Sectional with Bumper

114 x 87" 290 x 221cm 249 x 249cm

98 x 98"