


INSTALLATION INSTRUCTIONS



FLIP Flip-Down LCD Mount

NORTH AMERICA

3130 East Miraloma Avenue Anaheim, CA 92806 USA USA and Canada – Phone: 800-368-9700 Fax: 800-832-4888

EUROPE

Swallow House, Shilton Industrial Estate, Shilton, Coventry, England CV79JY Phone: +44 (0) 2476 614700 Fax: +44 (0) 2476 614710

Other Locations - Phone: (001)-714-632-7100; Fax: (001)-714-632-1044

©Premier Mounts 2009 9531-017-011-00





Warning Statements	. 2
Parts List	. 3
Installation Tools	. 3
FLIP Mount Location	. 4
Hardwood Cabinet Installation	. 5
Softwood Cabinet Installation	. 6
Mount Installation - Wall Surface (Optional)	. 7
Attaching the Flat Panel	. 8
FLIP Mount Adjustments	. 9
Final Adjustments	. 9
Technical Specifications	. 10
Warranty	. 11

Warning Statements



PRIOR TO THE INSTALLATION OF THIS PRODUCT, THE INSTALLATION INSTRUCTIONS SHOULD BE READ AND COMPLETELY UNDERSTOOD. THE INSTALLATION INSTRUCTIONS MUST BE READ TO PREVENT PERSONAL INJURY AND PROPERTY DAMAGE. KEEP THESE INSTALLATION INSTRUCTIONS IN AN EASILY ACCESSIBLE LOCATION FOR FUTURE REFERENCE.



PREMIER MOUNTS DOES NOT WARRANT AGAINST DAMAGE CAUSED BY THE USE OF ANY PREMIER MOUNTS PRODUCT FOR PURPOSES OTHER THAN THOSE FOR WHICH IT WAS DESIGNED OR DAMAGE CAUSED BY UNAUTHORIZED ATTACHMENTS OR MODIFICATIONS, AND IS NOT RESPONSIBLE FOR ANY DAMAGES, CLAIMS, DEMANDS, SUITS, ACTIONS OR CAUSES OF ACTION OF WHATEVER KIND RESULTING FROM, ARISING OUT OF OR IN ANY MANNER RELATING TO ANY SUCH USE, ATTACHMENTS OR MODIFICATIONS.



THE WALL STRUCTURE MUST BE CAPABLE OF SUPPORTING AT LEAST 5 TIMES THE WEIGHT OF THE FLAT PANEL. IF NOT, THE WALL STRUCTURE MUST BE RE-INFORCED. PROPER INSTALLATION PROCEDURE BY A QUALIFIED SERVICE TECHNICIAN, AS OUTLINED IN THE INSTALLATION INSTRUCTIONS, MUST BE ADHERED TO. FAILURE TO DO SO COULD RESULT IN SERIOUS PERSONAL INJURY, OR EVEN DEATH.



SAFETY MEASURES MUST BE PRACTICED AT ALL TIMES DURING THE INSTALLATION OF THIS PRODUCT. USE PROPER SAFETY GEAR AND TOOLS FOR THE INSTALLATION PROCEDURE TO PREVENT PERSONAL INJURY.



Indicates that the power plug is to be disconnected from the power outlet.



Contact Premier Mounts with any questions - (800) 368-9700.



Safety precautions must be taken at all times.



Warning and Caution statements.



It is recommended that a maximum of 5/8" plaster board be used when mounting to wooden studs.



Do not install on a structure that is prone to vibration, movement or chance of impact. Failure to do so could result in damage to the flat panel and/or damage to the mounting surface.



Do not install near heater, fireplace, direct sunlight, air conditioning or any other source of direct heat energy. Failure to do so may result in damage to the flat panel and could increase the risk of fire.



At least two qualified people should perform the installation procedure. Injury and/or damage can result from dropping or mishandling the flat panel.

Page 2 Installation Instructions




Parts List




NOTE

Congratulations on the purchase of your new Premier Mounts FLIP flat panel mount. This mount is shipped with all proper installation hardware and components. Make sure that none of these parts are missing and/or damaged before beginning installation. If there are parts missing and/or damaged, please stop the installation and contact Premier Mounts (800) 368-9700.



Installation Tools (not supplied)



Installation Instructions Page 3



FLIP Mount Location




Before drilling, make sure that there is enough room to lower and raise the display. For example, when the display is put in the "up" position, it should not hit the wall and should be even with the front of the cabinet.



NOTE Mount placement will be primarily determined by the size of the flat panel being used.



There must be enough clearance for the FLIP mount and flat panel to be adjusted without interfering with the wall, counter top surface and the overhead cupboard (see diagram below).



When mounting the FLIP mount to the underside of a cupboard, careful consideration must be taken.

The following steps will help in determining the placement of the FLIP mount (please see diagram above):

- **Step 1**. Attach the flat panel to the FLIP mount (SEE PAGE 8).
- **Step 2**. Put the FLIP mount in the "up" position.
- **Step 3**. Place the FLIP mount base flush on the underside of the cupboard.
- **Step 4**. Slide flat panel and FLIP mount to the rear of the cupboard surface until the bottom edge of the flat panel is a minimum 1" from the wall.

Step 5. Use a pencil to mark where the two mounting holes are. This will be the location where your pilot holes will be drilled.


Page 4 Installation Instructions



Hardwood Cabinet Installations



NOTE Wood screws are recommended when mounting the FLIP mount onto hardwood surfaces.




Step 1. Place the FLIP Mount base on the mounting location and mark (using a pencil) where the FLIP will be mounted.



The FLIP mount base may be used as a template when marking the mount location.



Prior to drilling into the underside of the



Installation Instructions Page 5




Step 3. Line the FLIP Mount up with the two pre-drilled mounting holes and use two (2) #14 x 7/8" wood screws and secure the FLIP Mount to the underside of the cabinet using a screwdriver.



WARNING


Do NOT over-tighten the wood screws, as this could cause the threads to strip out the wood inside the cabinet enclosure.



Softwood Cabinet Installation




NOTE 1/4-20 Tee Nut and screws are recommended when installing the FLIP mount into softwood surfaces.



- Step 1. Use a 5/16" drill bit and drill to pre-drill the tee nut pilot holes in the underside of the cupboard.
- **Step 2**. After drilling the mounting holes, open the cupboard door and place two (2) 1/4 20 tee nuts into each hole (see inset above). Use a hammer to gently tap into place.
- **Step 3**. Line the FLIP Mount up with the two pre-drilled mounting holes.
- **Step 4**. Using a screwdriver, insert and tighten two (2) 1/4 20 x 5/8" screws and attach the FLIP Mount to the underside of the cabinet.


Page 6 Installation Instructions

Mount Installation - Wall Surface (Optional)




Step 1. If the location where the flat panel will be installed is acceptable, use a stud finder to determine the exact center of each stud.

Step 2, Once a wood stud has been located, mark this spot with a pencil. This will be the upper mounting point.




Before drilling the pilot holes, line up the mounting holes with the pencil marks and level the FLIP mount, if needed.

Step 4. Using a 1/8" drill bit, pre-drill both pilot holes at the marked locations.



Step 3. Mark the lower mounting point as well, once the upper mounting point has been marked.



Step 5. Using a portable drill, insert and tighten two (2) #14 x 2" wood screws.



WARNING Do NOT over-tighten the wood screws, as this could cause the threads to strip out the wood inside the wall stud.


Installation Instructions Page 7



Attaching the Flat Panel



If you chose not to use the 360° feature of the FLIP mount, please insert and tighten one (1) M5 x 10mm flat head screw into any one of the four mounting point locations (please see below for mounting points). The M5 x 10mm flat head screw will prevent the FLIP mount from rotating 360°.



NOTE


If you chose not to use the 360° feature of the FLIP mount, please insert and tighten one (1) M5 x 10mm flat head screw into any one of the four mounting point locations (please see above for mounting points). The M5 x 10mm flat head screw will prevent the FLIP mount from rotating 360°.

- **Step 1**. Locate the mounting points that are on the back of the flat panel.
- Step 2. Line up the mounting points on the flat panel with the corresponding mounting holes on the FLIP mount.
- **Step 3**. Loosely attach the upper two (2) M4 x 10 mounting screws.
- Step 4. Insert the screw heads into the corresponding keyhole mounting slots that are on the FLIP mount.
- Step 5. With the FLIP mount securely attached, insert and tighten the two (2) lower M4 x 10 mounting screws.
- **Step 6**. Use a screwdriver to tighten all mounting hardware at this time.


Page 8 Installation Instructions

Ý


FLIP Mount Adjustments



Vertical Adjustment



360° Rotation Adjustment




Left-to-Right 360° Rotation Adjustment

Final Adjustments

The FLIP mount has pivots points that allow the mount to be easily adjusted. Once the adjustments have been made, the pivot points will need to be tightened. Please refer to the steps below to tighten the pivot point screws.

- **Step 1.** Make sure the FLIP mount has been adjusted to the determined viewing angle.
- Step 2. Locate each pivot point.
- **Step 3.** Use the 5/32" Allen wrench (supplied) to tighten each pivot point screw.





Installation Instructions Page 9



Technical Specification

All measurements are in inches [mm].





Page 10 Installation Instructions

Y

Warranty

PREMIER MOUNTS LIMITED LIFETIME WARRANTY

What and Who is Covered by this Limited Warranty and for How Long

Premier Mounts warrants this product to be free from defects in material and workmanship for the lifetime of the original owner of this product. The limited warranty is valid only for the original purchaser of the product.

What Premier Mounts Will Do

At the sole option of Premier Mounts, Premier Mounts will repair or replace any product or product part that is defective. If Premier Mounts chooses to replace a defective product or part, a replacement product or part will be shipped to you at no charge, but you must pay any labor costs.

What is Not Covered; Limitations

PREMIER MOUNTS DISCLAIMS ANY LIABILITY FOR DAMAGE TO MOUNTS, ADAPTERS, DISPLAYS, PROJECTORS, OTHER PROPERTY, OR PERSONAL INJURY RESULTING, IN WHOLE OR IN PART, FROM IMPROPER INSTALLATION, MODIFICATION, USE OR MISUSE OF ITS PRODUCTS.

PREMIER MOUNTS DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. PREMIER MOUNTS IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO, INABILITY TO USE ITS PRODUCTS OR LABOR COSTS FOR REMOVING AND REPLACING DEFECTIVE PRODUCTS OR PARTS. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

What Customers Must Do for Limited Warranty Service

If you discover a problem that you think may be covered by the warranty you MUST REPORT it in writing to the address below within thirty (30) days. Proof of purchase (an original sales receipt) from the original consumer purchaser must accompany all warranty claims. Warranty claims must also include a description of the problem, the purchaser's name, address, and telephone number. General inquiries can be addressed to Premier Mounts Customer Service at 1-800-368-9700. Warranty claims will not be accepted over the phone or by fax.

Premier Mounts Attn: Warranty Claim 3130 East Miraloma Ave. Anaheim, CA 92806

How State Law Applies

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

Installation Instructions Page 11