










## Components and Hardware List




<b>Leg</b>  <b>(A)</b> 4 pcs.	<b>Table Top</b>  <b>(B)</b> 1 pc.	<b>Top Leaf</b>  <b>(C)</b> 1 pc.
<b>M5/16" x 2-1/2" Allen Head Bolt</b>  <b>(D)</b> 8 pcs.	<b>5/16" Spring Washer</b>  <b>(E)</b> 8 pcs.	<b>5/16" x 19mm Flat Washer</b>  <b>(F)</b> 8 pcs.



#21250  
Rectangular Dining Table

<b>5mm Allen Wrench</b>  <b>(G)</b> 1 pc.	<b>Leveler</b>  <b>(H)</b> 4 pcs.
---	--

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.



To prevent possible scratches and damage, this furniture must be assembled by two people on a soft surface such as a blanket or carpet.

**Step 1:** Place the Table Top upside down. Attach a Leg (A) into each corner of the Table Top using the Allen Head Bolts (D), Spring Washers (E) and Flat Washers (F). Tighten using the Allen Wrench (G). Using two people, carefully set the assembled table upright.

**Step 2:** To install the Table Top Leaf, reach underneath the sides of the Table Top and twist the handle of the Locks to unlock. Using two people, lift the table off the floor, and pull the two halves of the Table Top open, place the Leaf in position, aligning the pins with the holes on the edges and push the halves back together. Reach underneath the Table Top and relock.

To prevent undue stress on the Dining Table, using two people, always lift and carry your Dining Table from one location to another.