

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. The Top has been secured to the apron frame for shipping and to assist in assembly. Do not remove the security strap until after the table has been completely assembled.

Step 1: Place the Table Top (J) upside down on a soft non-abrasive surface.

4 pcs.

Step 2: Attach the LEGS (K) to the underneath side of the Table Top with the 5/16" x 2 " long Allen-Head Bolts (A), Spring Washers (B) and Flat Washers (C). Do not fully install bolts until after shelf is assembled. Attach the Shelf (L) to the LEGS with the same 2" long Allen-Head Bolts and washers as previous step. Tighten all Bolts using the Allen Wrench (D).

4 pcs.

1 pc.

If the casters will be used: Attach the Wood Blocks (I) to the underneath side of the Shelf with the 1/4" x 2-1/2" long Allen-Head Bolts (E), Spring Washers (F) and Flat Washers (G). Tighten all Bolts using the Allen Wrench (H).

Step 3: Carefully set the Table upright and remove the security strap.

To prevent possible damage to some types of flooring, never roll casters on unprotected hardwood or vinyl flooring.

