

CONTENTS

-
- | | |
|---|----------------------------|
| 1 | Kickplate, stainless steel |
| 2 | Screw |
-

PROFESSIONAL STAINLESS STEEL KICKPLATE INSTALLATION

- 1 Remove the black kickplate, if installed.
- 2 Install the new kickplate using the screws provided.

