


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

223391Q (B1-B3)
Queen Bed

ITEM: 223391Q(B1-B3)



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION


B1 (BOX 1)

A HEADBOARD PANEL




1PC

C RIGHT HEADBOARD LEG




1PC

B HEADBOARD BOTTOM RAIL



1PC


D LEFT HEADBOARD LEG



1PC

B2 (BOX 2)

E FOOTBOARD



1PC

G LEFT FOOTBOARD LEG



1PC


F RIGHT FOOTBOARD LEG



1PC


B3 (BOX 3)

H BED RAIL



2PCS

J ROLL SLAT (11PCS)



1SET

I CENTER RAIL SUPPORT WITH LEVELER



3PCS

K CENTER RAIL




1PC

HB 223391Q (B1) FROM BOX 1 HEADBOARD COMPLETE



1PC

FB 223391Q (B2) FROM BOX 2 FOOTBOARD



1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 223391Q(B1-B3)

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.





WARNING!







1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION






Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 223391Q (B1)

1	BOLT ($\varnothing 5/16"$ x 45MM - RBW)		10PCS	2	LOCK WASHER ($\varnothing 5/16"$ - RBW)		10PCS
3	FLAT WASHER ($\varnothing 5/16"$ - RBW)		10PCS	4	ALLEN WRENCH (4MM - RBW)		1PC

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 223391Q (B2)

5	BOLT ($\varnothing 5/16"$ x 55MM - RBW)		4PCS	6	LOCK WASHER ($\varnothing 5/16"$ - RBW)		4PCS
7	FLAT WASHER ($\varnothing 5/16"$ - RBW)		4PCS	8	ALLEN WRENCH (4MM - RBW)		1PC

Z-B3 (BOX 3) - HARDWARE PACK IS LOCATED IN 223391Q (B3)

9	THREADED BOLT ($\varnothing 5/16"$ x 90MM - RBW)		8PCS	10	HALF ROUND NUT ($\varnothing 5/16"$ - RBW)		8PCS
11	HEX NUT ($\varnothing 5/16"$ x 14MM - RBW)		8PCS	12	WRENCH (14MM - RBW)		1PC
13	FLAT HEAD SCREW ($\varnothing 4$ x 30MM - RBW)		12PCS				


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: 223391Q(B1-B3)

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2





ITEM: **223391Q(B1-B3)**

ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4




ITEM: **223391Q(B1-B3)**

ASSEMBLY INSTRUCTIONS

STEP 5




STEP 6 COMPLETE



ITEM: **223391Q(B1-B3)**



Inner Size : 81.50"W X 61.00"D



Note: Dimension tolerance $\pm 5\%$