


Quick Reference Guide AutoChef®

Electric cooktop model: NETP0668SUC, NETP668SUC

This guide is not a substitute for the Use and Care Manual.

Read the Use and Care Manual for detailed instructions and important safety notices.



Setting the AutoChef® feature


Note:

- If AutoChef® is fitted on a two-circle cooking zone, the feature can only be used on the entire cooking zone.
- If **AutoChef**® is fitted on the three circle cooking zone of your cooktop, the outer heating ring is not available while using this feature.
- If only the inner section of the cooking zone is activated, the additional ring will automatically be turned on once you select the **AutoChef**® feature

Place the pan in the center of the heating element.


- 1. Select the cooking zone with the AutoChef® feature.
- 2. Touch the AutoChef key. \square and the rindicator light up in the element display.

The frying levels 1 - 5 appear in the settings area.



3. Select the desired frying level using the number keys on the display menu.

AutoChef® is activated.



The Important indicator blinks until the set frying temperature is reached. Then a beep sounds. The Important indicator stops blinking.

4. Add the frying oil to the pan, then add the ingredients.

Turn the food over as usual to avoid burning.

Turning off AutoChef®

Select the heating element and touch **AutoChef**.

AutoChef® Frying Chart			
		Frying level	Total frying time from signal
Meat	Pork chop, boneless or bone-in (1" thick)	3	10 - 17 min
	Veal cutlet in breadcrumb (%" thick)	4	6 - 10 min
	Beef steaks medium rare (¾" thick)	5	8 - 10 min
	Beef steaks medium or well done (¾" thick)	4	8 - 12 min
	Skillet-fried chicken	2	25 - 35 min
	Hamburger	3	6 - 12 min
	Ground meat	4	6 - 10 min
Fish	Fish fillet with or without breadcrumbs	3/4	10 - 20 min
	Shrimps	4	4 - 8 min
Egg dishes	Pancakes	3	continuous frying
_88	French toast, Omelettes	2	continuous frying
	Fried eggs	2	2 - 6 min
	Scrambled eggs	2	2 - 4 min
Potatoes	Hash browns	2	20 - 30 min
- Otatocs	Fried boiled potatoes	5	6 - 12 min
Vegetables	Garlic/onions	1/2	2 - 10 min
	Squash, egg plant	3	4 - 12 min
	Stir-fried vegetables	4	10 - 12 min
Frozen	Chicken nuggets, chicken patties	4	8 - 15 min
products	Fish fillet in breadcrumbs	3	10 - 20 min
•	Fish sticks	4	8 - 12 min
	Stir-fried vegetables	2	8 - 15 min
	Spring rolls/eggrolls (¾ - 1¼" thick)	3	10 - 30 min
Sauces	Tomato sauce with vegetables	1	25 - 35 min
	Béchamel sauce	1	10 - 20 min
	Cheese sauce, e.g. Gorgonzola sauce	1	10 - 20 min
	Reducing sauces, e.g. Bolognese sauce, tomato sauce	1	25 - 35 min
	Desert sauces, e.g. orange sauce	1	15 - 25 min
Ready-made meals	Potato products, e.g. fried potatoes	3	10 - 15 min
•	Potato products, e.g. hash browns	2	10 - 20 min
	Pasta (with added water)	2	4 - 6 min
Misc.	Baked camembert/baked cheese	3	7 - 10 min
-	Roast almonds, nuts, pine kernel*	2	3 - 7 min

^{*} Place in cold pan

Cooking safety

WARNING

If **AutoChef**® is not working properly, overheat may result causing smoke and damage to the pan.

When cooking with AutoChef® observe the following:

- · use the system pan for frying
- always put the pan in the center of the heating element
- do not place a lid on the system pan
- never leave frying fat unattended only use fat suitable for frying
- AutoChef® is not suitable for boiling
- When using butter, margarine or olive oil choose min

