
In-Use Screen

After a Massage program is selected, In-use screen displays all settings to that program.



- 1 Program
- 2 Indicators
- 3 Time remaining
- 4 Active airbags
- 5 Airbag intensity
- 6 Massage techniques
- 7 Back-roller position & direction
- 8 Massage speed

Auto Programs

Quick - Rapid demonstration of all massage techniques and chair motions.

Full Body - Comprehensive massage session using deep tissue kneading, and tapping combines with air cell compression.

Recover - Massage session focused on back and leg/foot region muscle recovery.

Focus - Performs a series of grab, hold, and stretch sequences while the back and legrest move up and down. This is combined with traditional massage techniques.

Relax - Massage session built for winding down with slower paced massage techniques.

All Air - This massage uses only airbags for a full-body compression massage, alternating between the feet, calves, seat, arms, hands, and shoulders.

Share a photo and tag us:

@Infinitymassagechairs

@infinity_chairs



INFINITY°

Don't forget to use #lovemyinfinitychair

72 Stard Road, Seabrook, NH 03874 603-910-5000 www.infinitymassagechairs.com

INFINITY®

Quick Start Guide



Prelude Massage Chair

Power - Powers up the remote or returns the chair to the exit position and powers down remote. LCD Screen Displays the current massage program and settings. Timer - Press to adjust your massage time in 5-minute increments, with a max massage time of 30 minutes.

Quick Auto Program - Press for a 6-minute demonstration of all available massage techniques.

Footrest Adjustment – Press and hold up arrow to raise the footrest, press and hold down arrow to lower footrest.

Heat - Press to turn on lumbar heat. Press button again to turn off lumbar heat.

Backrest Adjust – Press and hold down arrow to recline seat back, press and hold up arrow to upright the seat back.

Foot Rollers – Press to turn on foot roller massage. Press button again to turn off foot roller massage.

Massage Speed – Press to select your desired massage speed: Slow, Medium, or Fast.

Manual – Press to toggle between massage techniques: Kneading, Knocking, Kneading & Knocking, Tapping, or Shiatsu.

Back Zone – Press to select your desired back massage region: Point, Partial, or Whole massage.

Width – Press to select your desired back mechanism width when using Knocking, Tapping, or Shiatsu techniques: Narrow, Medium, or Wide.

Pause – Press to force stop the chair during a program and stop all functions. Press again to resume.

Zero Gravity – Press to turn on Zero Gravity. Press button again to turn off.

Auto Programs – Press any of the highlighted auto program buttons to jump to the corresponding program.

Airbag Intensity – Press to toggle the intensity of the airbag massage: Soft, Medium, or Strong.

Air Zone – Press once for foot air massage; twice for leg air massage; three times for leg and foot air massage; four times for arm air massage; five times for shoulder air massage. Press six times to turn off.

Back Roller Adjust - Press to set your shoulder height during body scanning.

